

Installation of Non-Adhesive Heater Mat

- 1 Ensure surface to be heated is clean of grease and dirt (use cleaning solvent if required).
- 2 Whilst the elements are flexible, care should be taken not to rough handle, fold or crease them.
- 3 Ensure H/SR heating element is clean of dust and dirt. (to clean use a damp cloth).
- 4 Apply a thin layer of suitable silicone rubber adhesive to cover the H/SR element side which is to be placed in contact with the surface to be heated in its entirety.
- 5 Place H/SR element into position, against surface to be heated and press firmly ensuring good, even contact.
- 6 Route and secure heater mat cold lead/cable
- 7 Visually inspect heater mat installation.
- 8 Electrically test heater mat for correct element resistance reading and earth isolation.
- 9 Equipment that the heater mat is fitted to should provide protection against electrical shock according to relevant European standards.

Holroyd Components Ltd.
Shire Hill Industrial Estate,
Saffron Walden, Essex
CB11 3AQ United Kingdom
Tel: +44 (0) 1799 523177
Fax: +44 (0) 1799 513714
sales@holroydcomponents.com
www.holroydcomponents.com



Holroyd Components
ISO9001:2000
File No. A10510

